





# SWINGING BALLET

SWINGING BALLET IS A REGISTRATED DESIGN BY COEN MUNSTERS 2009



<b>SWINGING BALLET H6</b>	BASE: 6 X E14 / 220V / MAX. 40W - CHAIN CA. 1,5 MTR.
<b>12910</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET H12</b>	BASE: 12 X E14 / 220V / MAX. 40W - CHAIN CA. 1,5 MTR
<b>12914</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET H18</b>	BASE: 18 X E14 / 220V / MAX. 40W - CHAIN CA. 1,5 MTR
<b>12918</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET F1</b>	BASE: 1 X E27 / 220V / MAX. 100W, INCL. REGULAR / DIMMER
<b>12980</b>	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET T1</b>	BASE: 1 X E27 / 220V / MAX. 60W
<b>12970</b>	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET T1</b>	BASE: 1 X E27 / 220V / MAX. 60W
<b>12972</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET W1</b>	BASE: 1 X E14 / 220V / MAX. 40W
<b>12950</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET W2</b>	BASE: 2 X E14 / 220V / MAX. 40W
<b>12954</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391

<b>COLORS</b>	02 CHROME CHROME
	05 BRONZE ALTMESSING
	10 BLACK MATT SCHWARZ MATT
	12 BLACK GLOSSY SCHWARZ POLIERT
	13 WHITE GLOSSY WEISS POLIERT
	14 WHITE MATT WEISS MATT
	16 MATT NICKEL NICKEL MATT

<b>SWINGING BALLET W3</b>	BASE: 3 X E14 / 220V / MAX. 40W
<b>12958</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET H5</b>	BASE: 5 X E14 / 220V / MAX. 40W
<b>12922</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET H7</b>	BASE: 7 X E14 / 220V / MAX. 40W
<b>12926</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET H10</b>	BASE: 10 X E14 / 220V / MAX. 40W
<b>12930</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET H14</b>	BASE: 14 X E14 / 220V / MAX. 40W
<b>12934</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET H17</b>	BASE: 17 X E14 / 220V / MAX. 40W
<b>12938</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391
<b>SWINGING BALLET H23</b>	BASE: 23 X E14 / 220V / MAX. 40W
<b>12942</b> SWAROVSKI® STRASS®	COLORS 00 01 02 05 10 12 13 14 16 SHADE 301 310 320 377 391

<b>SHADE</b>	301 WHITE WEISS
	310 CREME CREME
	320 BLACK SCHWARZ
	377 BROWN BRAUN
	391 RED ROT

**GENERAL INFORMATION:** - OTHER COLORS ON REQUEST  
 - CYRSTAL: SWAROVSKI® STRASS®  
 - MIDDLE BASE ARTICLE 12910, 12914, 12918: OTHER LENGHTS ON REQUEST